


Multicolored Preschool Ladder

SKU: DGS-PSL


Step 1:

Insert all rungs into the holes on one side of the ladder. Secure each rung using the included bolts.



Step 2:

Attach the other side of the ladder, ensuring the rungs fit into their corresponding holes. Finally, tighten all the bolts securely.



Part Number	Part Description	Quantity
Tarritarriser	<u>'</u>	addininy
CUSTOM	Ladder Side	2
CUSTOM	Multicolor Ladder Rungs (6ft Ladder)	7
	Multicolor Ladder Rungs (8ft Ladder)	9
0140708	Allen Head Bolts (6ft Ladder)	14
	Allen Head Bolts (8ft Ladder)	18
7289A15	4mm Allen Wrench	1



Need help?

Call 1-800-932-3339 or Email info@gymsupply.com