



Cliffhanger/Pegboard Offset Mounting Clamp

Need help? Call us at 1-800-932-3339 or email info@gymssupply.com

Cliffhanger/Pegboard Offset Mounting Clamp

Parts Included:

- 2 - Clamp Front Assembly
- 2 - Clamp Back Assembly
- 8 - Bolts, Nuts, Lockwashers and Flat Washers

Tools/Additional Materials Needed:

3/4" Socket and Wrench


Instructions:

Step 1:

Hand tightening 4 bolts, mount the clamp to the upright and measure to be sure clamps for each end are at the same height and high enough to allow clearance for the upright pads. Bolt heads should be on the front facing side to allow clearance when pegboard is installed.

Step 2:

Using a crossing pattern, tighten bolts a little at a time to ensure even clamping on the upright. Repeat with second clamp.



WARNING: These items are not toys. Activities involving motion and height create inherent risk of serious injury including paralysis or death. These products are intended for use by properly trained participants under qualified supervision, and the user of this product therefore assumes this risk. Always know your physical limitations and limits of your equipment. Avoid landing on head or neck as serious injuries may result. Always check for proper mat positioning, equipment stability, and inspect hardware for wear and damage before and after each use. Do not use if signs of damage or excessive wear are present. DGS shall not be liable for personal injury or property damage incurred through the use of purchased items.



Cliffhanger/Pegboard Offset Mounting Clamp




Need help? Call us at 1-800-932-3339 or email info@gymssupply.com

Step 3:

Mount Cliffhanger/Pegboard using included bolts. Pegboard should mount with 4 bolts on one side, and two on the other, allowing an additional pegboard to be mounted if desired. Tighten to clamps, with bolt heads on the front face.

Step 4:

Using included bolts, attach filler block at end of pegboard to cover remaining two bolt holes in bracket.



WARNING: These items are not toys. Activities involving motion and height create inherent risk of serious injury including paralysis or death. These products are intended for use by properly trained participants under qualified supervision, and the user of this product therefore assumes this risk. Always know your physical limitations and limits of your equipment. Avoid landing on head or neck as serious injuries may result. Always check for proper mat positioning, equipment stability, and inspect hardware for wear and damage before and after each use. Do not use if signs of damage or excessive wear are present. DGS shall not be liable for personal injury or property damage incurred through the use of purchased items.